The Shepherd Auto Feeder Operator Guide.

2. Containment Interval Feeding Timer Settings

Page Items	Register	Function
1. Sheep Number	DR2F=00000	Enter the number of sheep in the pen. Eg DR2F=00400 Head
2. Interval Timer	RE1= SU-SU 07:00 ON 22:00 Off	Set the daily time period for Interval Timer to be active. Set time period to 07:00 ON until 22:00 OFF. This means the feeder will operate from 7am to 10pm daily. Note 24hr clock settings. Disable all other programs On and Off times to 00:00.
2. Feed Duration	DR0A=00002	Set the time period for the feeder to turn ON and feed. The feeder turns ON during the duration time and turns OFF for the interval time. Eg DR0A=00002, The feeder will run for 2 minutes at a time followed by the interval.
Feed Interval	DR0B=00060	Set the Interval time between feeds in Minutes. This means the feeder stays OFF for this period. For example, DR0B=00060. The feeder will stay turned OFF for 60 minutes between each ON period.
Feed Limit Grams/Head	DR2D=02000	Sets the Daily Feed Limit across all programs for any 24hr period for each animal based on Grams/Head. Example DR2D=02000 and Sheep Number DR2F=00200. (DR2D=02000grams x DR2F=00200) = 400kg Feed limit. Default setting is 2000grams
Note		All other programs must have their active time periods set to 00:00. Avtivate Containment Interval Timer by turning on the silver toggle switch on the outside of the controller. **Ensure Manual Mode is not acitivated and left ON.**

www.autofeeder.com.au/support